




TRANSFORMER TABLE ARMSTRONG




Assembly instruction

TRANSFORMER TABLE ARMSTRONG


690x890x750

690x1780x750




C28

M8




B6



40x40

A9




4


4

2

C30



C25



M6x50

B19




8

6


6

No	L x W	Q-ty
1	670x40	4
2	890x80	1
3	890x80	1
4	890x599	2

1





2




3

B19




4

C25




M6x50

B6



40x40



5

