






TV stand scandinavian Asgard











Assembly instruction

TV stand scandinavian Asgard


1530x400x495




A30  20	C19  M8x60 5	G25  d-20 mm 5	A16  20*1,2 70
B3  50	B4  24	A1  6,4x50 44	G42  200 mm. 5
A11  3,5*16 62	A13  3,5*30 6	A26  4*45 3	G13  3
A10  8x35 mm 16	G41  5	C6  L-350mm 3	G1  3
A5  1			

No	L x W	Q-ty
1	254x400	1
2	1053x402	1
3	255x400	1
4	462x381	1
5	1530x403	1
6	254x363	1
7	254x400	1
8	350x140	1
9	350x140	1
10	405x140	1
11	405x140	1
12	433x346	1
13	456x186	1
14	462x253	1
15	1016x254	1
16	350x200	2
17	350x200	2
18	443x200	2
19	443x200	2
20	471x346	2
21	1010x248	1

1



2



3

