




Transformer-table Sensei







Assembly instruction


Transformer-table Sensei

530x900x750


3300x900x750



12 14 18 16



2 2 4 4




8 2 2


No	L x W	Q-ty
1	552x901	5
2	265x901	2
3	579x98	1
4	579x98	1

1

G46



A21



B18




2


2

2


B7



G47





C18




3

G48




B6




A13

4




G21



4

5



6

